

INSTALLATION INSTRUCTIONS

MEASURING AND INSTALLATION INSTRUCTIONS – ARCH TOPS AND TRANSOM TOPS

Step 1

Electric drill, ¼" (6mm) drill bit, hammer, clips, shutter fasteners. (¼" (6mm) carbide drill bit is required for stucco, hardboard, fibre cement, brick, or masonry.)

Step 2

Drill holes in shutter and wall as shown in the instructions on pages 4-5.

Step 3

Also, drill ¼" (6mm) hole into the Arch/Transom Top and 2½" (64mm) into the wall as shown below.

Step 4

Grasp the shutter fastener by supporting the shank, and push it through the shutter hole and into the wall surface. Tap the shutter fastener gently with a hammer to snug the shutter and Arch/Transom Top against the siding. Do not over tighten, or this will cause the shutter to dimple.

